



Quick Guide The Konftel 200W conference phone


English

Conference phones for every situation




DESCRIPTION – KONFTEL 200W

Konftel 200W is a DECT conference phone with a pickup range up to 30 m². The Konftel 200W connects to different makes of GAP-compatible DECT systems. If your office does not have a compatible DECT system, Konftel can supply a DECT base station for analogue connection.




Connecting and installing

Plug the Konftel 200W in the mains using the power adapter as illustrated. Place the conference phone in the middle of the table.



ANSWERING AND MAKING CALLS

Answering calls



A ring tone will be heard and the blue LEDs start flashing.

⇒ Press **OK** to answer.

The display shows the duration of the call.

Making calls




⇒ Press **OK**.



0-9...

⇒ Dial the number.

or




0-9...

⇒ Dial the number.




⇒ Press **OK**.

The number is called within 3 seconds.



The display shows the duration of the call.

Redialling



⇒ Press the up arrow.

The last number that you dialed appears in the display.



⇒ Press **OK**.

The number is called within 3 seconds.

Speed dialling

Please refer to the manual for instructions on adding and updating numbers in the phonebook.



⇒ Press the **Up/down** keys repeatedly.

The pre-programmed names in the phonebook appear in alphabetical order. The last dialled number appears first.




⇒ Press **OK** to call the selected name/number.

The number is called within 3 seconds.


DURING A CALL

Adjusting the speaker volume



⇒ Increase the speaker volume using + and lower it using -.

Mute function



⇒ Press the **mute** key to turn the microphone off.
The LEDs change from blue to red. The other party cannot hear what you are saying.



⇒ Press the **mute** key again to turn the microphone back on.

Adjusting the sound manually

Konftel 200W adjusts itself automatically when you switch it on to eliminate echo. It also senses changes in the room and continually adapts during the call. If, despite this, you still experience reduced sound quality, Konftel 200W can be adjusted manually at any time.



⇒ Press **c**.
A short noise is heard.


Ending calls



⇒ End the call by pressing **OK**.

REGISTERING IN A DECT BASE STATION

You need to register your Konftel 200W in a DECT base station before it can be used. Here we explain how to register in a **Konftel DECT base station**. To register your Konftel 200W in other makes of base station, simply follow the same procedure. Please refer to your base station instruction manual or contact your company's switchboard administrator if you are unsure.

















Set Konftel DECT base station in registration mode

⇒ Press and hold the key/LED on the base station until it starts to flash.

The base station is now in registration mode. Once registration has been completed, the LED will stop flashing. If the base station does not identify a DECT phone within 2 minutes, the registration mode will switch off automatically.

Register Konftel 200W in a DECT base station

	⇒ Press the MENU key.
	⇒ Select the menu tool using the Up/down key.
	⇒ Press OK .
	⇒ Select the menu Reg using the Up/down key.
	⇒ Press OK .
	⇒ Select a base (1–4).
	If no base station has been programmed, choose no. 1. Numbers that are ticked are being used.
	⇒ Press OK .
	⇒ Select a DECT system.
	⇒ Press OK .
	⇒ Enter the security code (PIN code) (standard code is 0000).
	⇒ Press OK .
	Some DECT systems (not Konftel DECT Base Station) require a PARK code. Check with your company's switchboard supplier.
	⇒ Enter the PARK code if this is required. Otherwise, leave blank.
	⇒ Press OK .
	Your Konftel 200W is now in registration mode and is searching for a base station in registration mode. Wait until you receive confirmation that registration has been completed. Registration can be interrupted by pressing C . If registration was successful, the word Done will appear in the display.
	⇒ Press OK .
	The Konftel 200W is now ready to use.

Konftel is a leading company within loudspeaker communication and audio technology. We develop and sell products and technology for telephone conferences based on cutting-edge expertise within acoustics and digital signal processing. Characteristic of our products is that all conference telephones contain the same high quality audio technology – OmniSound® providing crystal clear sound. Read more about Konftel and our products on **www.konftel.com**.

Developed by Konftel AB
Box 268, SE-901 06 Umeå, Sweden
Phone: +46 90 706 489 Fax: +46 90 131 435
E-mail: info@konftel.com Web: www.konftel.com
