

## Konftel 300IP and iCentrex


### What you need

- A iCentrex account
- A Konftel 300IP (software version 2.0.5 or higher) with internet connection

### Installation

Login to your Konftel 300IP and enter the account settings that you have. **Make sure that you enter the proxy settings as outbound proxy and that you end the address with ;lr**

Enter the **outbound proxy** as  
**bc.s.icentrex.com;lr**



**Account 1**

Enable account  Yes  No

Account name  **3rd party SIP phone username**

User  **3rd party SIP phone username**

Registrar  **Domain**

Proxy

Realm  **3rd party SIP phone username**

Authentication name

Password  **3rd party SIP phone password**

Registration interval

**Advanced**

Enable SIP Replaces  Yes  No

Enable Blind Transfer  Yes  No

Allow contact rewrite  Yes  No

Outbound proxy  **Outbound proxy**

**Transport**